



CCK Cable Connector Kit

- > 10 feet of multicolored ribbon cable
- > Four IDC 10 pin connectors

1. Cut ribbon cable to desired length. If the optional cable restraint is used approx. 1/2" of cable is required per connector.
2. Gently separate connector parts to make room for inserting ribbon cable. Connector parts may have separated during shipping, but are easily re-assembled (direction does not matter). Cable restraint is separate.
3. Insert ribbon cable lining up the brown wire with the "pin one" indicator arrow.



4. Using a vice or crimp tool press the connector parts together.

NOTE: Use of this cable with a SRC16 and MotoD requires a second connector. If attaching a second connector, we recommend that both "pin one" indicator arrows face the same direction. This ensures ease in connecting products.

